



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.



Rev. 03-12-2020

**Modular Pin Wheel Pocket Stabilizer**

Part No. **PPP-MPWPS**



To install reinforcement ribs between pockets, place rib over pocket and insert spacers into both parallel (horizontal) mounting holes. Spread pocket 1/16" to align remaining hole and insert spacer.

Spread adjacent pocket 1/16" and join to rib-installed side and secure.