



Rev. 03-12-2020

## PPP-CRHI

SQUEEZE URETHANE BLOCK INTO CURTAIN ROD HOLDER. INSERT SMALL SCREWDRIVER BETWEEN INSIDE OF CURTAIN ROD HOLDER AND BLOCK. PUSH URETHANE SIDE TABS TOWARD HOLE IN HOLDER BRACKET. REMOVE SCREWDRIVER AND SQUEEZE SIDES OF INSERT TO SETTLE TABS INTO BRACKET HOLES.



Rev. 03-12-2020

## PPP-CRHI

SQUEEZE URETHANE BLOCK INTO CURTAIN ROD HOLDER. INSERT SMALL SCREWDRIVER BETWEEN INSIDE OF CURTAIN ROD HOLDER AND BLOCK. PUSH URETHANE SIDE TABS TOWARD HOLE IN HOLDER BRACKET. REMOVE SCREWDRIVER AND SQUEEZE SIDES OF INSERT TO SETTLE TABS INTO BRACKET HOLES



Rev. 03-12-2020

## PPP-CRHI

SQUEEZE URETHANE BLOCK INTO CURTAIN ROD HOLDER. INSERT SMALL SCREWDRIVER BETWEEN INSIDE OF CURTAIN ROD HOLDER AND BLOCK. PUSH URETHANE SIDE TABS TOWARD HOLE IN HOLDER BRACKET. REMOVE SCREWDRIVER AND SQUEEZE SIDES OF INSERT TO SETTLE TABS INTO BRACKET HOLES.



Rev. 03-12-202

## PPP-CRHI

SQUEEZE URETHANE BLOCK INTO CURTAIN ROD HOLDER. INSERT SMALL SCREWDRIVER BETWEEN INSIDE OF CURTAIN ROD HOLDER AND BLOCK. PUSH URETHANE SIDE TABS TOWARD HOLE IN HOLDER BRACKET. REMOVE SCREWDRIVER AND SQUEEZE SIDES OF INSERT TO SETTLE TABS INTO BRACKET HOLES