



Rev. 02-18-2020
Ball Booster to Light Bar Step
Part No. **PPP-LBS** – pkg of 1



Mount 2 forward brackets to rearward pit light mounting holes - moderately secure with supplied longer bolts choosing appropriate number of washers for c-channel spacers.

Mount 2 rear brackets to the normally empty holes in c-channel - moderately secure with supplied hardware - again choosing appropriate number of washers for c-channel spacers.

Insert carriage bolts into step plate counter-bore holes and place into slotted bracket holes. Using flat washer only and nut, draw carriage bolts fully into counter-bore holes.

Undo carriage bolts - center and firmly secure step plate, this time including lock washers.

The slightly slotted lower bracket holes allow for differences or variations in c-channel heights. When needed, adjust step plate level by lifting corner (or end) before firmly securing. Firmly secure remaining bracket mounting hardware.



Rev. 02-18-2020
Ball Booster to Light Bar Step
Part No. **PPP-LBS** – pkg of 1



Mount 2 forward brackets to rearward pit light mounting holes - moderately secure with supplied longer bolts choosing appropriate number of washers for c-channel spacers.

Mount 2 rear brackets to the normally empty holes in c-channel - moderately secure with supplied hardware - again choosing appropriate number of washers for c-channel spacers.

Insert carriage bolts into step plate counter-bore holes and place into slotted bracket holes. Using flat washer only and nut, draw carriage bolts fully into counter-bore holes.

Undo carriage bolts - center and firmly secure step plate, this time including lock washers.

The slightly slotted lower bracket holes allow for differences or variations in c-channel heights. When needed, adjust step plate level by lifting corner (or end) before firmly securing. Firmly secure remaining bracket mounting hardware.