

INSTALLATION INSTRUCTIONS

PART NUMBER	154-8806C
PART DESCRIPTION	KEYPAD ASSEMBLY – CROSSFIRE MODEL C
REV DATE	11/28/2011
MACHINE MODELS	CROSSFIRE MODEL C



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Phillips Screwdriver 11/32" Wrench

Please thoroughly read the instructions prior to performing the installation of this assembly. To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below



• Place orders with Distributor

• Maintenance reminders on phone

Software updates

How to videos

Take full control of your lane machine at My.kegel.net

Kegel's Lane Maintenance Central: Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 via e-mail at LMC@Kegel.net website www.kegel.net



- 1) Disconnect power & lay the machine down in the operating position.
- 2) Using the Phillips screwdriver & 11/32" wrench, loosen & remove the fasteners securing the existing keypad mounting bracket from the rear & right side frame panels.
- 3) Unscrew the cable from the serial port on the back of the existing keypad assy.
- 4) Loosen the keypad mounting tabs, securing the keypad to the mounting bracket. Remove keypad from the bracket.
- 5) Install the replacement keypad into the bracket cut-out, and secure in place w/ the mounting tabs removed in step #4.
- 6) Plug the keypad cable into the serial port in the back of the keypad and screw the plug in place.
- 7) Using the fasteners removed in step #2, mount the bracket back into the machine, making sure to completely tighten all of the screws.
- 8) Apply power to the machine and check for proper operation of the new keypad.



Place orders with Distributor

• Maintenance reminders on phone

Software updates

How to videos

Take full control of your lane machine at My.kegel.net

Kegel's Lane Maintenance Central: Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 via e-mail at LMC@Kegel.net website www.kegel.net