



## Removal of cover

1. Remove the grey cover from the rear of the charger by removing the 2 screws.
2. Loosen the three screws securing the white plastic strain relief bar & remove.
3. Remove the red and black wires from the circuit board.
4. Fasten the cord assembly with the Red wire to the POS position and the Black wire to the NEG position.
5. Install the white stress relief bar and tighten screws completely.
6. Use the supplied wire ties to secure the wires approximately 1" back from the heat shrink.
7. Re-install grey cover.

