## **INSTALLATION INSTRUCTIONS**



Part Number:	163-8011
Part Name:	Crossover Wedge
Revision Date:	April 7,2015
Written By:	Don Agent
Approved By:	William Walters

## Packaging Contents:


Qty.	Part Number	Description
1 set	163-8011	Crossover Wedge
163-2006	M4 Lock nut	QTY - 6
163-2007	M4 Flat Washer	QTY - 6
163-2008	M4 X 20 M. Screw	QTY - 4
163-2009	M4 X 25 M. Screw	QTY - 2

## **Tools Required**


2.5mm hex wrench7 mm Wrench or socket with ratchet4.4 mm or 11/64" drill bitSpring clamp or C-clamp

1 Remove power from the Gamesetter. Use proper Lock Out/ Tag Out procedures.

2. Measure from the top of the Crossover side rail downward 12mm. and mark. Repeat 2 more times to allow for proper height for installation.



3. Line the thinest edge of the Crossover Wedge at the rearward crease in the side rail and hold in place with a clamp.



4. Drill mounting holes using the Crossover Wedge as a template. Install Crossover Wedge with hardware

Kegel's Pinsetter Parts Technical Support 1-800-280-2695 Or internationally at 863-734-0200<br/>Email kpp@kegel.net or visit our website at www.kegel.net/pinsetterpartsREV 03/12<br/>Page 2 of 3

provided.

5. Remove all tools and clean drill shavings from the belts and Gamesetter. Restore power.