



YOUR LANES | OUR PASSION

INSTALLATION INSTRUCTIONS

PART NUMBER	153-8844
PART DESCRIPTION	RECOVERY TANK FILTER ASSEMBLY
REV DATE	7/16/2015
MACHINE MODELS	PXS-A,B / PX-8 A, B / Crossfire



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Phillip Screwdriver
Putty Knife

Flathead Screwdriver
Clean Rags

Silicone



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81



Take full control of your
lane machine at
My.kegel.net

- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



Rev. 3.14

1. Lay the machine down in the operating position. Disconnect the inlet from the side of the recovery tank and the outlet hose from vacuum plate by removing the PVC elbows. Empty the Recovery Tank.
2. Remove tank from machine and dispose of used cleaner **properly**. Do NOT dump recovery tank in a septic tank or sanitary sewer system. Follow your local environmental regulations for the best method of disposal.

NOTE: When dumping liquid from Recovery Tank, it is best to let liquid flow out the inlet end, or the end that was connected to the squeegee assembly. If liquid accumulates between baffles on the opposite side of tank, dirty cleaner may be discharged from the vacuum exhaust and onto the lane until the line is cleared. Rinsing the inside of the tank daily with clean water will decrease the need to clean the filter material.

3. Set the tank on a flat surface. Remove the phillips screws from both covers, and using a flat-head screwdriver, gently pry covers off. Clean silicone residue from both covers and the tank.
4. Remove the filter material from the tank and dispose of. Flush and clean out the inside of the tank with hot water or with new cleaner. Use a clean rag to wipe any dirt or residue from the inside of the tank.
5. Fold the replacement filter material in the correct position in tank. Place a bead of silicon on the area where both covers will seat. Replace fasteners in both covers and tighten down. DO NOT over-tighten. Allow silicone to cure before operating machine.
6. To reconnect the tank, reverse the disconnect procedure.



Take full control of your
lane machine at
My.kegel.net

- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



Rev. 3.14