

Use broken corners for shims or use washers lower than remaining plate height. Grind plate weld or strap for clearance before securing.



Pkg. of 2



Use broken corners for shims or use washers lower than remaining plate height. Grind plate weld or strap for clearance before securing.



Rev.02-12-2020

PPP-5CMR

Pkg. of 2



Use broken corners for shims or use washers lower than remaining plate height. Grind plate weld or strap for clearance before securing.



Rev.02-12-2020

PPP-5CMR

Pkg. of 2



Use broken corners for shims or use washers lower than remaining plate height. Grind plate weld or strap for clearance before securing.