




Installation Instructions

PART NUMBER	157-8817	
PART DESCRIPTION	TORCH LIGHT TILT BAR TRIGGER SYSTEM	
REV DATE	12/4/2018	
MACHINE MODELS	TORCH	

TOOLS NEEDED	PARTS
Phillips Screwdriver 3/32 allen wrench	
TECHNICAL NOTE	
Please thoroughly read the instructions prior to performing the installation of this assembly. To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.	

STEPS

Switch Height Adjustment:

1. The switch can be adjusted to change difficulty or customize for your height of capping. Loosen the screw and adjust the height to be lower for easier or higher for harder.





Tilt Bar Assembly

1. With the light bar removed from the stand, remove the two 3/32 allen screws from the black holder.



2. Take the tilt assembly and remove the fastener at the bottom and take your phillips screwdriver and tighten the screws into place.



3. Replace the black knob into place and reattach the light bar assembly.
-