

INSTALLATION INSTRUCTIONS

PART NUMBER	164-8660
PART DESCRIPTION	FLEX WHISKER ASSEMBLY
REV DATE	4/10/2020
MACHINE MODELS	FLEX WALKER



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Ruler 1/8" allen wrench Superglue

PARTS INLCUDED:

1-164-8660 Whisker assembly



Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available! www.youtube.com/user/KegelBowling81

KEGEL TECH SUPPORT: Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 via e-mail at LMC@Kegel.net website www.kegel.net



Installation of New Whisker assembly

- 1. Start with the lane machine in the up position.
- 2. Loosen the two set screws located in the bottom of the whisker mounting block assembly.
- 3. Remove the old whisker assembly and insert the new whisker assembly into the mounting block.
- 4. Insert the whisker so that a measurement of $5 \frac{3}{4}$ " is reached between the edge of the mounting block and the very tip of the whisker assembly.
- 5. Tighten the set screws.
- 6. Inspect the operation of the whiskers while the lane machine is traveling onto the lane.

