



INSTALLATION INSTRUCTIONS

| | |
|------------------|-------------------------------------|
| PART NUMBER | 164-8007 |
| PART DESCRIPTION | OIL SUPPLY TANK VENT VALVE ASSEMBLY |
| REV DATE | 4/14/2020 |
| MACHINE MODELS | FLEX / FLEX WALKER 2013-2018 |



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:
Phillips Screwdriver
11/32 Wrench



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81

KEGEL TECH SUPPORT:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



1. With the machine in the operating position, remove the oil pump cover assembly by removing the two phillip screws holding it in place. To remove the cover, it's easier to remove the entire oil plate assembly by loosening and removing the thumb screw holding the plate in place.



2. Remove the clamp screw holding the Vent Valve assembly to the plate.

Clamp screw

3. Remove the old Vent Valve from the connector.
4. Insert the new Vent Valve assembly in place and reinstall the clamp onto the plate assembly.
5. Reinstall the oil plate assembly and cover back in place.

