




Rev. 02-12-2020

Gear Box Oil Level Dipstick

Part No. **PPP-DIP**

Sight glass is often a cloudy unreliable indicator.



Over filling can cause seal leakage.
Add oil when below bottom line.
Bottom line is lowest sight glass area.
Top line is middle of sight glass.

Easier than stooping to observe sight glass. Position Dipstick at about 11 o'clock to the left side of worm gear and push into oil fill hole until rod hits bottom of gear box.




Rev. 02-12-2020

Gear Box Oil Level Dipstick

Part No. **PPP-DIP**

Sight glass is often a cloudy unreliable indicator.



Over filling can cause seal leakage.
Add oil when below bottom line.
Bottom line is lowest sight glass area.
Top line is middle of sight glass.

Easier than stooping to observe sight glass. Position Dipstick at about 11 o'clock to the left side of worm gear and push into oil fill hole until rod hits bottom of gear box.




Rev. 02-12-2020

Gear Box Oil Level Dipstick

Part No. **PPP-DIP**

Sight glass is often a cloudy unreliable indicator.



Over filling can cause seal leakage.
Add oil when below bottom line.
Bottom line is lowest sight glass area.
Top line is middle of sight glass.

Easier than stooping to observe sight glass. Position Dipstick at about 11 o'clock to the left side of worm gear and push into oil fill hole until rod hits bottom of gear box.




Rev. 02-12-2020

Gear Box Oil Level Dipstick

Part No. **PPP-DIP**

Sight glass is often a cloudy unreliable indicator.



Over filling can cause seal leakage.
Add oil when below bottom line.
Bottom line is lowest sight glass area.
Top line is middle of sight glass.

Easier than stooping to observe sight glass. Position Dipstick at about 11 o'clock to the left side of worm gear and push into oil fill hole until rod hits bottom of gear box.




Rev. 02-12-2020

Gear Box Oil Level Dipstick

Part No. **PPP-DIP**

Sight glass is often a cloudy unreliable indicator.



Over filling can cause seal leakage.
Add oil when below bottom line.
Bottom line is lowest sight glass area.
Top line is middle of sight glass.

Easier than stooping to observe sight glass. Position Dipstick at about 11 o'clock to the left side of worm gear and push into oil fill hole until rod hits bottom of gear box.