Installation Instructions

PART NUMBER	157-8818	
PART DESCRIPTION	BATTERY BOX MOUNT	
REV DATE	11/20/2018	
MACHINE MODELS	TORCH, TORCH X	DIFFICULTY

TOOLS NEEDED	PARTS		
7/16 SOCKET 7/16 WRENCH			
TECHNICAL NOTE			
Please thoroughly read the instructions prior to performing the installation of this assembly. To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.			

STEPS

- 1. Remove the two mounting bolts at each end of the bracket assembly, but leave the middle bolt.
- 2. Remove the pin on the Torch frame to bend the leg as shown in Figure 1.
- 3. Slide the head of the middle bolt down the frame slot 6" from the top, and tighten the bolt with the bracket assembly horizontally as shown in Figure 2.
- 4. Fasten the battery box into place as shown in Figure 3.





BUILT FOR BOWLING®

Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 www.kegel.net E-Mail: tech@kegel.net

Rev. 9/20

