



INSTALLATION INSTRUCTIONS

| | |
|------------------|------------------------------------|
| PART NUMBER | 154-8651A & 154-8652A |
| PART DESCRIPTION | CLEANER PUMPJ REPLACEMENT STANDARD |
| REV DATE | 09/06/2005 |
| MACHINE MODELS | SANCTION STANDARD |



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Phillips Screwdriver

11/32" wrench



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81



- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Take full control of your lane machine at My.kegel.net

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



Rev. 3.14

1. Lay the machine down in the operating position. Remove the (4) screws holding the pump mounting box to the frame.
2. Unplug the pump from the harness wiring, and also remove ground wire fastener from the mounting box.
3. Release the hoses from the quick release fittings on the water pump (press collet down and slide hose out) and remove the mounting box with pump out of the machine.
4. Once out of the machine, remove the screws fastening the pump to mounting box.
5. Install the new pump into the mounting box and fasten. Place the mounting box into position on the machine.
6. Secure pump ground wire to mounting box and plug pump into harness wiring.
7. Align mounting holes up and screw flathead screws back down, tightening box to frame.
8. You will now need to insert the elbow fitting that is attached to the union tee, into the left side of the pump. Insert the remaining elbow fitting into the right side of the pump.
9. Connect the elbow on the right side of the pump to the supply line from the Cleaner Supply Tank. Connect the long piece of tubing on the tee fitting to the fitting that leads to the spray jets. Connect the other side of the tee fitting to the return line of the Cleaner Supply Tank.
10. Run the machine and check for any leaks.



- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Take full control of your
lane machine at
My.kegel.net

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net

