



Rev. 03-12-2020

PPP-PG1

**“Pozi-Grip”™ Ball Wheel Strips w/ “Pozi-Nose”™**

(Patent Pending)

***Installation Instructions***

Clean 16 in. area of ball wheel

Use cleaners that leave no soap residue (isopropyl alcohol)

Remove Backing and install “Pozi-Grip”™ to cleaned area

Remove Backing and install “Pozi-Nose”™ in front of “Pozi-Grip”™ leading edge

Flat end of “Pozi-Nose”™ should match up with leading edge of “Pozi-Grip”™

Do not clean “Pozi-Grip”™ with power applied to pinsetter

Pinsetter should be powered down to prevent injury and premature wear to product



Rev. 03-12-2020

PPP-PG1

**“Pozi-Grip”™ Ball Wheel Strips w/ “Pozi-Nose”™**

(Patent Pending)

***Installation Instructions***

Clean 16 in. area of ball wheel

Use cleaners that leave no soap residue (isopropyl alcohol)

Remove Backing and install “Pozi-Grip”™ to cleaned area

Remove Backing and install “Pozi-Nose”™ in front of “Pozi-Grip”™ leading edge

Flat end of “Pozi-Nose”™ should match up with leading edge of “Pozi-Grip”™

Do not clean “Pozi-Grip”™ with power applied to pinsetter

Pinsetter should be powered down to prevent injury and premature wear to product



Rev. 03-12-2020

PPP-PG1

**“Pozi-Grip”™ Ball Wheel Strips w/ “Pozi-Nose”™**

(Patent Pending)

***Installation Instructions***

Clean 16 in. area of ball wheel

Use cleaners that leave no soap residue (isopropyl alcohol)

Remove Backing and install “Pozi-Grip”™ to cleaned area

Remove Backing and install “Pozi-Nose”™ in front of “Pozi-Grip”™ leading edge

Flat end of “Pozi-Nose”™ should match up with leading edge of “Pozi-Grip”™

Do not clean “Pozi-Grip”™ with power applied to pinsetter

Pinsetter should be powered down to prevent injury and premature wear to product