

INSTALLATION INSTRUCTIONS

PART NUMBER	153-7005R
PART DESCRIPTION	MOMENTARY WHEEL
REV DATE	11/7/2011
MACHINE MODELS	ALL



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

.050" Allen Wrench



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81



• Place orders with Distributor

Take full control of your lane machine at My.kegel.net

• Maintenance reminders on phone

- Software updates
- How to videos

Kegel's Lane Maintenance Central: Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 via e-mail at LMC@Kegel.net website www.kegel.net



Rev. 3.14

- 1) Using the .050" Allen Wrench, loosen the set screw in the Momentary Wheel Housing.
- 2) Push the Momentary Wheel shaft out of the housing & old wheel.
- 3) Place the new Momentary Wheel inside the housing and push the shaft through, making sure the shaft flat spot is on the same side as the set screw, and faces up towards the threaded hole.
- 4) Making sure the set screw is seated on the shaft flat spot, tighten the set screw completely.



• Place orders with Distributor

• Maintenance reminders on phone

Software updates

How to videos

Take full control of your lane machine at My.kegel.net

Kegel's Lane Maintenance Central: Within USA - 1-800-280-2695 Outside USA - +1 863-734-0200 via e-mail at LMC@Kegel.net website www.kegel.net

