



INSTALLATION INSTRUCTIONS

PART NUMBER	154-8806
PART DESCRIPTION	KEYPAD ASSEMBLY
REV DATE	11/18/2011
MACHINE MODELS	KUSTODIAN PLUS, ION



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Phillips Screwdriver



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81



- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Take full control of your lane machine at My.kegel.net

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



- 1) Disconnect power and lay machine down in the operating position.
- 2) Open the machine splashguard to access bottom of the keypad.
- 3) Unscrew & remove the keypad cable.
- 4) Loosen the two keypad mounting bracket screws, and remove the brackets.
- 5) Place the new keypad into the splashguard. Install the keypad mounting brackets on each side of the keypad. Screw the mounting bracket screws up into the bottom of the splashguard to secure the keypad in place. ***Do not over-tighten the mounting screws or you could crack the keypad housing.***
- 6) Plug the cable into the serial port in the bottom of the new keypad. Screw the two cable plug screws into the threaded inserts in the keypad until tight.



- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Take full control of your
lane machine at
My.kegel.net

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net

