



YOUR LANES | OUR PASSION

INSTALLATION INSTRUCTIONS

PART NUMBER	154-8901
PART DESCRIPTION	TRANSFER BRUSH ADJUSTING TOOL
REV DATE	03/03/2011
MACHINE MODELS	ALL TRANSFER BRUSH LANE MACHINES



Basic knowledge of the operation of the lane machine



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81



Take full control of your lane machine at My.kegel.net

- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



Rev. 3.14

This tool is used to make the adjustment of the Transfer brush a little easier to gain the 3/16" of crush evenly across the front side of the brush and approx 1/16" across the backside.

In the event the transfer brush is need of an adjustment:

1. Slightly loosen the four 8/32 screws on the right and left that secure the adjustment blocks to the bar but keep them snug.
2. Using the transfer brush adjustment tool, turn the setscrews clockwise to raise the transfer brush or counter clockwise to lower the transfer brush.
3. Position the transfer brush so it is just touching the buffer brush then turn it counter clockwise to lower the transfer brush into the buffer brush so you have approx. 3/16" of crush evenly across the front side of the brush and approx 1/16" across the backside.
4. Once the adjustment has been made, tighten the 8-32" screws to secure your adjustment.



Take full control of your
lane machine at
My.kegel.net

- Place orders with Distributor
- Maintenance reminders on phone
- Software updates
- How to videos

Kegel's Lane Maintenance Central:
Within USA - 1-800-280-2695
Outside USA - +1 863-734-0200
via e-mail at LMC@Kegel.net
website www.kegel.net



Rev. 3.14