



INSTALLATION INSTRUCTIONS

PART NUMBER	164-8017F
PART DESCRIPTION	RECOVERY TANK FILTER - FLEX
REV DATE	4/14/2014
MACHINE MODELS	FLEX / FLEX WALKER



Basic knowledge of the operation of the lane machine

TOOLS NEEDED:

Phillips screwdriver

silicone

PARTS INCLUDED:

(1) – 164-8017F - Filter Assembly



TECHNICAL NOTE

Please thoroughly read the instructions prior to performing the installation of this assembly.

To avoid any potential problems, if at any time during the process you have a question, stop and contact our Tech Support department at the numbers listed below.

Please visit our growing library of videos to see if these instructions are available!



www.youtube.com/user/KegelBowling81

KEGEL TECH SUPPORT:

Within USA - 1-800-280-2695

Outside USA - +1 863-734-0200

via e-mail at LMC@Kegel.net

website www.kegel.net



1. Remove the screws securing the recovery tank top cover to the tank.
2. Remove the top plate of recovery tank. It may be necessary to pry the top plate up with a screwdriver.
3. If replacing the gasket, remove it and clean the old silicone from around the opening in the top of the tank.
4. Remove the old filter from inside of the Recovery tank and discard.
5. Install the new recovery tank filter into the slot between the tank filter dividers with the 'cut out corners' portion of the filter toward the top.
6. If installing a new gasket, put a small bead of silicone around the perimeter of the tank opening and place the gasket into position. Align the holes in the gasket with the plate mounting screw holes.
7. Reinstall the top plate using the mounting screws, tightening completely. Use a zig zag pattern when fastening the screws.

